



N.B. S1 MUST BE WIRED EXACTLY AS SHOWN ON MODULE LAYOUT DRAWING ML60359

1 = (-70dBm)
 2 = HZ. (1200Ω)
 3 = L.Z. (300Ω)

NOTE:- SEE MODULE INTERNAL LAYOUT DIAGRAM ML60359 FOR DETAILS OF SENSITIVITY SWITCH ASS'Y

5	4	3	2	1	ISSUE	FIRST USED ON A428 - A436	MAT'L.	TOL. UNLESS OTHERWISE STATED	
8-6-72	22-3-72	16-3-72	1-3-72	3-12-71	DATE	DRN. M.G.B.	FINISH	LINEAR ±	ANGULAR ±
10526	10485	10478	10460		CHANGE NOTE NO	TRACED N.J.T.	TITLE	HOLES +005 -000	DIMS IN SCALE
					CHECKED	CHECKED	1290 MICROPHONE AMPLIFIER	DRG. NO	EN10041
							Rupert Neve & Company Ltd.	1971	©A2